

Owl Box



Philip Preorius
082 388 8788
philpret@mweb.co.za

Cutting list

4 Sides: 300mmx400mmx20mm
1 Back : 300mmx260mmx20mm
1 Front Ledge : 300mmx40mmX20mm
2 Top in front for the arch: 150mmx 100mmx20mm
2 Perch supports: 200mmx50mmx20mm
1 340mmx13mm dowel

Other material

33 Eureka self-cutting screws 4.5 mm x 40 mm

Assembly

Step 1: Assemble the 1st two sides at a 90 degree angle using 3 screws



Step 2: Assemble the 3rd side at a 90 degree angle using 3 screws



Step 2: Assemble the last side using 2 screws on each side



Step 4: Insert and assemble the back using 2 screws on each side





Step 4: Cut the two top blocks at an angle of about 30degrees leaving 20mm at the top and the side. Assemble at the top using 3 screws per block.



Step 5. Attach the ledge in front of the bottom with 2 screws



Step6 - Drill a 13mm hole for the dowel and attach the perch support on each side of the bottom with 2 screws



Step7: Sand and paint or varnish