

**DIY SOLUTIONS** 





Scan this QR code for the complete and free project



of the aprons. Clamp them in place and

secure with 5 x 50mm Eureka Cut screws.

0.0

ROAL DE

<sup>6.</sup> The complete coffee table will resemble this one. Go ahead, scan the QR code and get the complete project.